




Zero Knowledge Proof



Proof Pod

Screen Logic Guide



1) Quick Start

Requirements: internet connection, USB-C power source, account at ZKP.com.

Steps:

1. Connect the USB-C cable to the device and a power source.
2. Turn on the device (Power button).
3. Connect to Wi-Fi on the device screen.
4. On another device, open ZKP.com, log in, and link your wallet.
5. Enter the one-time code shown on the Proof Pod screen. Done.

Tips:

- The code changes about once a minute — always use the current one.

2) Interface Basics

The main screen shows:

- Level (Compute Level)
- Your stats (account balance, earnings, completed tasks)
- Network status (Wi-Fi icon)
- “ZKP Presale Live” card (purchase option)

Quick actions: Upgrade level, buy ZKP, change Wi-Fi.

Note: interface appearance and names may change centrally.

3) Device Level Upgrade

Why: higher level = higher performance.

How to upgrade:

1. Tap Upgrade on the main screen.
2. Scan the QR code and complete payment at ZKP.com.
3. The level will update automatically.

If it doesn't update: wait a little while and check again.

4) Buying ZKP

What you see: current round, price, your contribution, progress.

To purchase:

1. Open ZKP Presale Live.
2. Tap Buy ZKP.
3. Pay via QR / ZKP.com.



5) Network & Wi-Fi

- Change network: tap the Wi-Fi icon → select network → enter password.
- Status indicator:
 - Green — stable connection
 - Yellow — weak, may affect performance
 - Red — unstable connection
- No network: a “Connect to Wi-Fi” window will appear.

6) System Updates

- Updates are downloaded automatically over Wi-Fi.
- Do not disconnect power during an update.

7) Power & Battery

- Recommended: keep the device plugged in at all times.
- If mains power is lost: runs on backup battery (status shown on screen).
- Low battery: connect power to clear the notification.

8) Notifications

- Types: network, power, promotions, system messages.
- Control: close with “X” or tap outside the window.

9) FAQ

Wi-Fi won't connect

- Check the password
- Move closer to the router
- Reconnect
- Restart the router
- Try another network

Device won't turn on

- Check power source and cable
- Press Power
- Hold Power ~10 s
- Press Reset

Can't link device

- Use the current code
- Make sure you're logged in at ZKP.com
- Try again

Level didn't update after payment

- Wait a while
- Check payment status at ZKP.com

Update interrupted

- Check the network
- Wait for the next attempt